

# FORD

## F-250 SUPERCREW 2000 – 2007



### ALSO FITS: F-350 SUPERCREW 2000 – 2007

- Location: Behind the rear seat. Jack stays in factory location and tools relocate to under passenger side of enclosure. Must have rear bench seat.
- Molded in factory colors.
- Install hardware supplied.
- Available in Loaded & Amplified Models.

### SPECIFICATIONS

**Dimensions:** 6 $\frac{1}{8}$ "H x 30 $\frac{1}{2}$ "W x 10 $\frac{1}{4}$ "D

**Weight:** 23.2 lbs.

**Power Handling:** 225 Watts RMS

**Subwoofer:** One 10" Thunder4500

**Sensitivity:** 90dB

**Amplifier:** 200 Watt Class D

*(on amplified models only)*

**Enclosure Volume:** .75 cubic foot, sealed

**Impedance:** 4 Ohm

*(on un-amplified models only)*



COLOR	LOADED	AMPLIFIED
TAN	F250C00T10-T45	F250C00T10A-T45
CHARCOAL	F250C00C10-T45	F250C00C10A-T45
GREY	F250C00G10-T45	F250C00G10A-T45
BLACK	F250C00BK10-T45	F250C00BK10A-T45

# THUNDERFORM®

DUE TO CONTINUAL PRODUCT DEVELOPMENT, SPECIFICATIONS ARE SUBJECT TO CHANGE.

CALL: 1-800-CALL-MTX FOR CURRENT MODEL UPDATES



# Stock to Rock