

MTX JACKHAMMER

JH1200 – 1200 WATT MONO BLOCK, CLASS-D, JACKHAMMER AMPLIFIER

MTX WARRANTY STATEMENT

MTX JackHammer amplifiers purchased in the USA from an authorized MTX dealer are guaranteed against defects in material and workmanship for the period of 1 year if installed by an authorized MTX dealer (90 days if by customer). The warranty period begins the day the product is purchased by the end user. This warranty is limited to the original retail purchaser of product. Product found to be defective during that period will be repaired or replaced by MTX at no charge. This warranty is void if it is determined that unauthorized parties have attempted repairs or alterations of any nature. Warranty does not extend to cosmetics or finish. Before presuming a defect is present in the product, be certain that all related equipment and wiring is functioning properly. MTX disclaims any liability for other incurred damages resulting from product defects. Any expenses in the removal and reinstallation of products are not covered by this warranty. MTX's total liability will not exceed the purchase price of the product. If a defect is present, your authorized MTX dealer may be able to effect repairs.

Proof of purchase is required when requesting service, so please retain your sales receipt, and take a moment to register your product online at MTX.com. Also, a Return Authorization number (RA) is required before shipping product back to MTX, call 800-225-5699 or 602-438-4545, for amplifier RAs.

REQUIRED INSTALLATION TOOLS

- Ice Cold Soft Drink
- Adjustable Wrench
- Power Drill
- Utility Knife
- Crimper
- Allen Wrench

2 CONNECT SIGNAL

REMOTE TURN-ON /POWER ANTENNA WIRE
(Do not use with Smart Engage™ RCA to Line Level Adapters)

SETTINGS

SMART ENGAGE™
 OFF ON (Aftermarket Head Unit - Remote turn-on wire connected)
 OFF ON (Factory Head Unit - Remote turn-on wire not connected)

GAIN
 5V 0.25V
 Adjust input sensitivity to match source unit

SUB SONIC
 20Hz 50Hz
 Adjust Sub Sonic filter frequency

BASS BOOST
 0dB 12dB
 Adjust Bass Boost to increase bass response

LPF
 40Hz 200Hz
 Adjust Low Pass crossover frequency

1 CONNECT POWER

Ground To Metal of Vehicle (Remove Paint From Metal)

18"

Disconnect Battery Negative (-) Cable Prior to Installing Amplifier (Reconnect after step 3)

1/0 AWG 16 AWG 1/0 AWG

Connect to Source Unit Remote Turn-on /Power Antenna Wire

3 CONNECT SUBWOOFER(S)

12-8 AWG

12-8 AWG

≥1Ω

≥2Ω

≥2Ω

≥2Ω